

# GLOBAL THREADED INSERTS



PART #	DESCRIPTION	PACK
U20-341872	6-32 THREAD INSRT ST/ST USS	(F)
U20-341874	8-32 THREAD INSRT ST/ST USS	(F)
U20-341876	10-24 THREAD INSERT IMPL USS	(F)
U20-341878	1/4-20 THREAD INSERT IMPL USS	(F)
U20-341880	5/16-18 THREAD INSERT IMPL USS	(F)
U20-341882	3/8-16 THREAD INSERT IMPL USS	(F)
U20-341884	7/16-14 THREAD INSERT IMPL USS	(F)
U20-341892	1/2-13 THREAD INSERT IMPL USS	(F)
U20-341894	5/8-11 THREAD INSERT IMPL USS	(C)
U20-341896	3/4-10 THREAD INSERT IMPL USS	(C)
U20-341898	1"-8 THREAD INSERT IMPL USS	(B)
U20-341910	10-32 THREAD INSERT IMPL SAE	(F)
U20-341912	1/4-28 THREAD INSERT IMPL SAE	(F)
U20-341914	5/16-24 THREAD INSERT IMPL SAE	(F)
U20-341916	3/8-24 THREAD INSERT IMPL SAE	(F)
U20-341917	7/16-20 THREAD INSRT ST/ST SAE	(F)
U20-341918	1/2-20 THREAD INSERT IMPL SAE	(F)
U20-341920	5/8-18 THREAD INSRT ST/ST SAE	(C)

ASSORTMENT

- **GLOBAL** Thread Inserts are used in magnesium, aluminum, cast iron, copper, masonite, plastics. For load bearing threads in any material.
- **GLOBAL** Thread Inserts will not back out or vibrate loose.
- A nylon locking element in the external thread automatically locks the insert in place.
- Bolts and screws can be inserted and removed without insert movement.
- **No special tools needed.** Threads have standard external threads that permit the use of standard drills and taps.
  - Drill hole, countersink. Tap drill size given in dimension charts.
  - Tap hole same size as external thread.
  - Turn insert into place with a bolt and lock nut.  
Locking element holds in place.

