


ANCHORS

GLOBAL HAMMER DRIVE ANCHORS



- **FAST AND EASY TO USE**
- **SAVES TIME ON JOB – SAVES LABOR**
- **ELIMINATES HOLE SPOTTING**
- **SIMPLY DRILL PROPER SIZE HOLE AND DRIVE IN**
- **NO NEED FOR EXACT HOLE DEPTH**
- **HOLE BOTTOM NOT REQUIRED TO SET ANCHOR**

PART NUMBER	ANCHOR SIZE	GRIP RANGE	EMBEDMENT	DRILL DIAMETER	PULLOUT 3700PSI CONCRETE	PACK
L20-582110	3/16 X 7/8	0 – 1/8	3/4	3/16	500	(BAA)
L20-582120	1/4 X 3/4	0 – 1/8	5/8	1/4	500	(BAA)
L20-582130	1/4 X 1"	1/8 X 1/4	7/8	1/4	770	(BAA)
L20-582140	1/4 X 1-1/4	1/4 X 1/2	1-1/8	1/4	1050	(FA)
L20-582150	1/4 X 1-1/2	1/2 X 3/4	1-3/8	1/4	1200	(FA)
L20-582160	1/4 X 2"	3/4 X 1-1/4	1-7/8	1/4	1470	(FA)




GLOBAL INDUSTRIAL PRODUCTS

FEATURES:


- **QUICKLY HAMMERED INTO PLACE, EASE OF INSTALLATION**
- **TAMPER-PROOF**
- **CAN BE USED IN :**
 - **CONCRETE**
 - **BLOCK**
 - **BRICK**
 - **STONE**

EASE OF INSTALLATION


1. Drill hole in base material same diameter as anchor. Minimum depth of hole should be overall length of anchor minus thickness of material to be fastened.



2. Insert anchor through the object to be fastened and into hole in base material.



3. Tap nail until it is flush with hammer drive anchor head.



GLOBAL INDUSTRIAL PRODUCTS